



Steel discs riveted to grille the frame. -

Rare earth magnets screwed to the grille. -






Flush fit magnetic supply grille installed and painted

Step 1

- Provide blocking for drywall and flush fit grille frame.
- The edge of the metal duct must be flush with the blocking.
- · Paint the inside of the metal duct flat black.
- Measure the Width x Height of the metal duct.



Securely screw the flush fit grille frame to the wall framing.




Step 3

Cut and fit 5/8" drywall around the flush fit grille frame and screw it securely to the wall framing.

Note:

The flush fit frame should stand out aprox. 1/16" to 1/8" thicker than the drywall. This will allow for proper floating and feathering of the drywall mud finish. \neg



- Tape and mud the drywall to the flush fit grille frame.




Skim and finish the dry wall mud to flush out the grille frame.



Step 6

Finished and painted with magnetic grille installed.




Finished and painted with magnetic grille removed.



Installed examples





Installed examples

